

Aladdin

FULLY AUTOMATIC

Radiator Bleeder

- Easy fit: no adjustments necessary no need to drain the system
- Long, leak-free life
- Replaceable cartridge
- Saves energy & reduces fuel bills by keeping radiators air-free and hot to the top!
- Dispenses with the need for radiator bleed keys
- Reduces corrosion and system noise



HV 30C Radiator Auto Vent



5060123340037

NLB Engineering Ltd
 1 Cedar House
 Stonehall Business Park
 Downhall Road Matching Green
 Essex CM17 0RA

www.aladdin-nlb.com

SAVE £££'s
 SAVE ENERGY

Aladdin

FULLY AUTOMATIC

Radiator Bleeder

SPECIALLY DESIGNED TO FIT
STANDARD 1/2" BSP THREAD



Aladdin



MODEL – HV 30C : FITS STANDARD 1/2" BSP RADIATOR THREADS
 Other thread sizes available – ask in-store for details of other Aladdin products

Fitting Instructions

You will need an adjustable wrench to fit. We also recommend an old cloth to dry the radiator tapping.

1 Switch the central heating system off and allow to cool


2 Isolate the radiator

Avoid flooding by closing the isolator valves at the bottom of the radiator – at one end this will be a lockshield valve with a plastic cover – remove the cover and turn the spindle clockwise using the adjustable wrench.

At the other end will either be a wheelhead valve, which can be turned off by hand, or a thermostatic valve which should be turned to '0'.



Lockshield Valve



Wheelhead Valve




Thermostatic Valve

3 Remove the old manual vent

Unscrew the old manual vent plug using an adjustable wrench. Mop up any spillage with cloth.

Old Manual Vent



4 Fit the valve

Screw the valve into the radiator tapping, nip tight with the adjustable wrench.

Ensure that the cartridge in the middle of the valve is screwed all the way in (use the 'U' shaped insert tool across two of the vent holes).



5 Turn the valves back on

For full product information, please refer to the Aladdin website: www.aladdin-nlb.com

