

Portable charger

Comes pre-charged



- Charge your cellphone, AA batteries, iPod and digital devices
- Instant power wherever you are
- Flashlight function
- Recharge the included AA batteries to use in other devices too



Other tips are available at www.powertraveller.com

Pack contents:

- | | |
|---|----------------------|
| 1 Powerchimp | 8 Motorola V66 tip |
| 2 Carry case | 10 Sony Ericsson tip |
| 3 DC3.5 x 1.1 charging cable | 11 Female USB |
| 4 Retractable USB charging cable | 12 LG Chocolate tip |
| 5 2 x AA 1800mAh rechargeable batteries | 13 DC4.0 PSP tip |
| 6 iPod tip (colour may vary) | |
| 7 Samsung E900 tip | |
| 9 Mini USB | |
| 14 Mini Nokia tip | |



1. Battery compartment for 2xAA batteries in underside of powerchimp
2. Removable battery compartment cover
3. Power socket cover attached with flexible strap



1. Powerchimp being charged via USB
2. LED in red charge input mode
3. Retractable USB charging cable



Powerchimp is available in four colours: grey, blue, pink and yellow



Powerchimp is the lightweight portable charger that fits in your pocket to power up your devices day to day or in an emergency.

Supplied with two rechargeable AA batteries, powerchimp puts up to 48 hours of instant power at your fingertips, ready when you need it most.

Powerchimp is developed with a safety feature to protect against overcharging.

Easy to use, one button technology in a tough casing makes this the portable charger to take everywhere.

Important: Due to the possible length of time between the manufacturing and sale of the product, Powertraveller cannot guarantee the actual state of charge left in the Powerchimp. It comes fully charged and does not discharge at such a high rate as most standard Ni-MH rechargeable battery.

Before you use your Powerchimp for the first time, charge it fully for 12 hours. Always use the same type of rechargeable batteries.

- Ready to use instant power wherever you are
- Charge your cellphone, batteries, iPod and digital devices
- Compatible with standard cellphones (including Nokia and Mini-Nokia, LG Chocolate, Samsung, Siemens, Sony Ericsson and Motorola) and other digital devices
- Pocket size - big on power
- Pulse Charging technology ensures long battery life
- Soft touch one button technology - Auto Lock when charging or recharging
- Flashlight function
- Incorrect battery polarity protection - unit will not operate if you insert batteries incorrectly
- 2 AA Powertraveller long shelf life Ni-MH rechargeable batteries included for up to 48 hours extra power
- Standard AA batteries can be used but will not charge
- Powerchimp can accept most AA rechargeable batteries

How to use your powerchimp:



1. Tough outer shell
2. Soft function button
3. LED
4. Charging cable
5. Input/output socket with soft removable cover
6. Flashlight

To charge your cellphone, iPod and digital devices:

- To switch your powerchimp on, depress the black button (2) twice until LED (3) flashes green
- Select the right tip for your device. If the tip you need is not included in this pack, visit www.powertraveller.com
- Attach tip to charging cable (4)
- Connect charging cable to your cellphone or device through its standard charging socket
- Undo soft cover from top of powerchimp input socket (5) and connect cable
- LED green flashing light indicates charging
- Powerchimp turns itself off 2 minutes after fully charged
- LED flashing red light means unit needs charging

Recharge your rechargeable batteries:

Charge by connecting powerchimp to the USB port of your computer/laptop

LED solid red light indicates charging; if flashing red, it is not charging and will turn green when fully charged

Flashlight:

To activate press black button (2) three times.

Recharge your powerchimp:

- Flashing red light means unit needs recharging
- Fully charge your powerchimp from the USB on your laptop in 5 hours
- Plug tip of retractable USB charging cable into USB port of your laptop or other USB socket
- Plug other tip into powerchimp input socket
- LED is red when charging; LED turns green when fully charged
- May also be charged via mains and solar power



Use powerchimp to power up these devices:

- Cellphones - approx. 48 hours standby time and 4 hours talk time
- iPod - approx 20 hours; 4 hours if watching video
- AA rechargeable batteries - charge in approx. 2 hours
- MP3/MP4s - approx 3 hours
- PSPs - approx 2.5 hours
- PDAs - approx 24 hours

Note: actual times will vary according to charge in the batteries and quality of batteries used.

Extra charging accessories featured here can be purchased from www.powertraveller.com



Worldwide Mains/AC adaptor Solarmonkey AA rechargeable batteries

For customer support, please email: support@powertraveller.com

For additional tips not included in this pack, and to see the full range of Powertraveller devices and accessories visit www.powertraveller.com



MADE IN CHINA

Powertraveller Ltd
8 Delta Park, Wilsom Road, Alton
Hampshire, GU34 2RQ, UK

Tel: +44 (0) 1420 542980

